



Parts Needed:




Fast-feeder System:


- 1). Screw one of the rails at the bottom of the gate opening:**
This should be on the FRONT / OUTSIDE of the gate.
 Be sure the pins are pointed UP.
 Use the 1/4-20 x 1" pan-head screws to attach the rail.



- 2). Set the rotate-plate on the middle '+' pin:**
 Be sure the name 'Gator Kennels' is readable.



- 3). Drop the second rail '+' pin into the rotate-plate:**
 Use the 1/4-20 x 1" pan-head screws to attach the rail.



- 4). Attach the lock to the gate:**
 We spotted 4 holes for the lock screws to make it easier.
 The lock should fit into the slot on the rotate-plate.

The bowls drop in place when you are OUTSIDE the kennel:
 Note that you cannot add or remove the bowls when inside the kennel.
 This keeps the dogs from removing them.

